

Instructions for sampling shower water

Ideally, the sample should be collected in the morning before the first water use/shower and the sample should be sent on the day of collection.

Procedure:

1. Fill in the sampling sheet.



2. Collect 1 liter of **hot water** (mixer tap: set mixer lever to hot or open hot water tap) and without flow, collect the first liter of hot water directly from the **shower head** using the sample container.



3. Container well worn, enclose completed sampling sheet in the return box. Attach return address label and postage and send.



Important notes:

Test results will be sent in writing, at the latest 10 days after receipt of the sample by mabritec AG.

Upon request, the experts of mabritec AG are available to answer your questions regarding the legionella problematics.